FUN VOLLEY SET

Art.-Nr. / Item No.:
111108 (8,5 m) · 111108B · 111101 (9,5 m)

SPORTARTEN / SPORTS

BEACHVOLLEYBALL



BEACHTENNIS

QUALITÄT & SPIELNIVEAU / QUALITY & SKILL LEVEL

FUNTEC

LIEFERUMFANG SCOPE OF DELIVERY

Stückliste / Parts list		Menge / Qu.	Art.-Nr. / Item No.	Shop
1	**Stahl-Pfostenset, 6-teilig, 4 Schraubösen aus Stahl, 2 Bodenplatten aus Kunststoff** / *Metal pole set, 6-piece, 4 metal eye bolts, 2 plastic ground plates*	1	111416	
2	**Erdnagel** / *Sand anchor*	4	111408	
3	**Spanngurt, 2-teilig** / *Tension strap, 2-piece*	4	111407	
4	**Freizeitnetz, 8,5 m/9,5 m** / *Leisure sports net, 8.5 m/9.5 m*	1	111324/111322	
5	**Packtasche Fun Volley** / *Fun Volley bag*	1	111335	

AUFBAUANLEITUNG



Beide Netzpfosten setzen sich aus je drei Rohren zusammen. Das Rohr mit der schwarzen Kunststoffkappe ist das Oberteil. Schraube die Metallösen in die dafür vorgesehenen Löcher. Du kannst zwischen zwei Netzhöhen wählen.



Setze nun die gelben Spanngurte zusammen. Achte darauf, dass sich die Schlaufen am Ende der Gurte und nicht am Klemmschloss befinden. Auf diese Weise erhältst du vier Spanngurte. Streife die kleinen Schlaufen über die Erdnägel.



Die Positionen der Erdnägel werden folgendermaßen festgelegt: Entfalte dazu vollständig das Netz **(1)**. Die Schlaufen des oberen Spannseils markieren die Positionen der Netzpfosten **(2)**. Von hier aus werden die Erdnägel in einem 90°-Winkel in einer Entfernung von ca. 3 m platziert **(3)**.



Insgesamt erhältst du so vier Verankerungspunkte für die Erdnägel. Diese werden mit einem Hammer schräg (vom Pfosten weg) in den Sand geschlagen. Achte darauf, dass du vorher die kleinen Schlaufen der Spanngurte über die Erdnägelköpfe gelegt hast!

5



Hänge die großen Schlaufen der Spanngurte und die Schlaufen des Netz-Spannseils an der Spitze der Netzpfosten ein und stelle diese zum Spielfeld hin schräg auf.

6



Spanne alle vier Spanngurte gleichmäßig ab und stelle die Netzpfosten dabei senkrecht. Die roten Leinen werden an den Schraubösen an den Pfosten befestigt. Die gewünschte Netzspannung und genaue Netzhöhe stellst du über die unteren roten Spannleinen ein.



Die optimale Netzposition erreichst du durch Nachjustieren der Spanngurte und der unteren Spannleinen. Das Netz sollte genau in der Flucht der Netzpfosten hängen.

TIPPS

- Bevor du dein Set wieder verpackst, befreie insbesondere die Pfosten und Steckverbindungen vom Sand.
- Stecke die Erdnägel zur Aufbewahrung am besten in die Rohre. Dann können sie in der Tasche nicht herausfallen.

EMPFEHLUNGEN

Als Spielfeldmarkierung empfehlen wir dir die Fun Volley Courtline aus 5 mm starker, roter Kordel mit U-förmigen Stahlheringen.



BEACH VIBES HIGH FIVES

WITH FUNTEC

HENNEF · MADE IN GERMANY ·

SETUP MANUAL



Assemble the net posts from three parts. The section with the black cap is the top piece. Insert the metal eye bolts into the holes and secure with the wing nuts. You can choose between the two different holes to obtain different net heights.



Put the two parts of the yellow straps together as shown. Make sure the loops are positioned at the end of the straps and not near the metal clip lock. Slip the small loops over the sand anchors.



To obtain the ideal position for the sand anchors, unfold the net completely **(1)**. The loops of the top cable mark the positions of the net posts **(2)**. Knock the anchors into the ground at a distance of approx. 3 m from the post position **(3)** with an approx. 90° angle.

Make sure that you have placed the small loops of the tension straps over the anchor heads beforehand. Knock the anchors into the ground at a slight angle away from the posts to aid tensioning.



5



Put the large loops of the tensioning straps and the loops of the net tensioning rope over the top of the net posts and set them up at an angle towards the playing field.

6



Tighten the yellow straps and adjust the position of the post as necessery to get the posts upright. The net must be aligned midway between the poles by adjusting the short red ropes at the top of the net. Adjust the lower ropes to length at the metal loops at the poles.



The net tension and net height can be altered to achieve the perfect net by adjusting the tension of the red ropes at the bottom corners of the net.

TIPS

- Wipe the sand off the posts before storing them.
- Store all anchors together in one single pole section so they cannot drop out inside the bag.

RECOMMENDATION

We recommend the Fun Volley courtline as suitable for this portable Beachvolleyball set. The courtline has a 5 mm rope and comes with U-shaped metal anchors.

ANUALMANUALMANUALMA
NUALMANUALMANUALMA

FUN VOLLEY SET

Art.-Nr. / Item No.:
111108 (8,5 m) · 111108B · 111101 (9,5 m)

FUNTEC ONLINESHOP

FUNTEC WEBSITE

FUNTEC
Löhestr. 25 · DE - 53773 Hennef

+49 (0) 2242 3231
service@funtec.de
www.funtec.de